GREAT LAKES IPM INC.

PYRAMID TRAP ASSEMBLY INSTRUCTIONS

1. Working on a firm level surface, stand up panels A and D with slots facing each other (see illustra tion 1).
2. Slide panels A and D together making sure to align the slots.
3. Take panel C and slide tabs (two tabs) through both panel A and D. Make certain tabs are all the way through both panels. Pull down and lock into place.
4. Repeat step 3 for panel B. Again, make sure both panels A and D are locked into place.
5. After locking panels into place, all four panels should be even at top.
6. Place assembled trap in desired location. Taking two tent stakes, drive tent stakes into ground be side panels C and B until hook on tent stake is even with hole. Panels C and B have holes located near the bottom of each panel.
7. Once hook is connected to trap, gently tap stake down until trap is snug with ground. Be careful not to go to far.
8. Place plastic assembled unit on top of trap (see illustration 2).
9. Attach bread ties through holes near the bottom of trap funnel (at points F) and attach to holes in panel to hold funnel firmly on trap.
10. After assembly is complete, insert plastic screws through small holes in insertion tabs at point E.

Illustration 1



Illustration 2



Great Lakes IPM, Inc.
10220 Church Rd NE
Vestaburg MI 48891

989-268-5693
800-235-0285
FAX: 989-268-5311

www.greatlakesipm.com
E-mail: glipm@greatlakesipm.com